

Алматы (7273)495-231
 Ангарск (3955)60-70-56
 Архангельск (8182)63-90-72
 Астрахань (8512)99-46-04
 Барнаул (3852)73-04-60
 Белгород (4722)40-23-64
 Благовещенск (4162)22-76-07
 Брянск (4832)59-03-52
 Владивосток (423)249-28-31
 Владикавказ (8672)28-90-48
 Владимир (4922)49-43-18
 Волгоград (844)278-03-48
 Вологда (8172)26-41-59
 Воронеж (473)204-51-73
 Екатеринбург (343)384-55-89

Россия +7(495)268-04-70

Иваново (4932)77-34-06
 Ижевск (3412)26-03-58
 Иркутск (395)279-98-46
 Казань (843)206-01-48
 Калининград (4012)72-03-81
 Калуга (4842)92-23-67
 Кемерово (3842)65-04-62
 Киров (8332)68-02-04
 Коломна (4966)23-41-49
 Кострома (4942)77-07-48
 Краснодар (861)203-40-90
 Красноярск (391)204-63-61
 Курск (4712)77-13-04
 Курган (3522)50-90-47
 Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
 Москва (495)268-04-70
 Мурманск (8152)59-64-93
 Набережные Челны (8552)20-53-41
 Нижний Новгород (831)429-08-12
 Новокузнецк (3843)20-46-81
 Ноябрьск (3496)41-32-12
 Новосибирск (383)227-86-73
 Омск (3812)21-46-40
 Орел (4862)44-53-42
 Оренбург (3532)37-68-04
 Пенза (8412)22-31-16
 Петрозаводск (8142)55-98-37
 Псков (8112)59-10-37
 Пермь (342)205-81-47

Казахстан +7(7172)727-132

Ростов-на-Дону (863)308-18-15
 Рязань (4912)46-61-64
 Самара (846)206-03-16
 Санкт-Петербург (812)309-46-40
 Саратов (845)249-38-78
 Севастополь (8692)22-31-93
 Саранск (8342)22-96-24
 Симферополь (3652)67-13-56
 Смоленск (4812)29-41-54
 Сочи (862)225-72-31
 Ставрополь (8652)20-65-13
 Сургут (3462)77-98-35
 Сыктывкар (8212)25-95-17
 Тамбов (4752)50-40-97
 Тверь (4822)63-31-35

Киргизия +996(312)96-26-47

Тольятти (8482)63-91-07
 Томск (3822)98-41-53
 Тула (4872)33-79-87
 Тюмень (3452)66-21-18
 Ульяновск (8422)24-23-59
 Улан-Удэ (3012)59-97-51
 Уфа (347)229-48-12
 Хабаровск (4212)92-98-04
 Чебоксары (8352)28-53-07
 Челябинск (351)202-03-61
 Череповец (8202)49-02-64
 Чита (3022)38-34-83
 Якутск (4112)23-90-97
 Ярославль (4852)69-52-93

<https://bandelin.nt-rt.ru/> || bni@nt-rt.ru

SONOREX TECHNOLOGY MB 110.2 B LIFTING DEVICE



The lifting device makes work easier for the operator. It enables automatic oscillation into the cleaning or rinsing bath and facilitates the transport of the filled product baskets from tub to tub. The slowly oscillating up and down movement increases the cleaning effect of the ultrasound and the dissolved dirt is rinsed off better.

-The filled cleaning basket is hung manually in the lifting device. By switching the timer, the lifting device lowers the basket into the tub and automatically starts oscillation. After the timer has expired, the oscillation stops and the lifting device automatically lifts the basket out of the tub back into the starting position.- The lifting device is pushed manually with the suspended basket to the next tub.
 -By switching the timer, the lifting device lowers the basket into the tub and automatically starts oscillation again.

ORDER NUMBER	8327
OPERATION	Display
TIME SETTING [MIN]	1-99, infinite
OPERATING VOLTAGE [V]	400 V
MAINS CABLE	5
OUTER DIMENSION LENGTH [MM]	depending on the number of tubs
OUTER DIMENSION WIDTH [MM]	1100
OUTER DIMENSION HEIGHT [MM]	1700
DEGREE OF PROTECTION HOUSING	IP 20
CE MARKING	Machinery Directive 2006 / 42 / EC, EMC Directive 2014 / 30 / EU, RoHS Directive 2011 / 65 / EU
PAYLOAD [KG]	40
PACKING LENGTH [MM]	0
PACKING WIDTH [MM]	0
PACKING DEPTH [MM]	0